


Assembly & Operating Instructions

VT-623E



RobsWork.com
ENGLISH

IMPORTANT SAFETY NOTICES

Please read all instructions before using the fan. Keep these operating instructions in a safe place for future reference.

1. Position the fan where children cannot reach it.
2. Only connect the fan to a single-phase socket with the voltage specified on the type plate.
3. Always disconnect the plug from the mains when the fan is not in use, when it is being moved, touched or cleaned. Do NOT pull on the cable to remove the plug.
4. Completely unwind the cable. A cable, which has not been completely unwound, can overheat and cause a fire.
5. Do not use an extension lead or continuous speed control, since these could overheat, cause a fire or give off an electric shock.
6. The fan may only be used following the correct assembly of the front grill (#1) and the rear grill (#5) as described under “**Assembly Instructions**”
7. The fan must only be used in accordance with the instructions contained within these operating instructions. Non-observance of these instructions could result in injury, cause a fire or give off an electric shock.
8. The fan is for private use in interiors of buildings only. It is not for commercial use.
9. Do NOT use this fan if it is damaged or could be damaged, or if it does not work properly. Remove the plug from the socket.

DESIGN

- 1 - Front grill
- 2 - Fan nut
- 3 - Fan blade
- 4 - Back grill nut
- 5 - Back grill
- 6 – Handle
- 7 - Motor shaft
- 8 - Main unit
- 9 - Operating switch
- 10 - Oscillation button
- 11 - Tilting knob

RobbWork.com
ENGLISH

ASSEMBLY INSTRUCTIONS

1. Pick up the main unit (#8), which consists of the fan nut (#2) and the back grill nut (#4).
2. Loosen the fan nut (#2) in a clockwise direction and remove it from the motor shaft (#7)
3. Loosen the back grill nut (#4) in an anticlockwise direction and remove it from the motor shaft (#7)
4. Pick up the back grill (#5) so that the handle (#6) is pointing upwards
5. Place the back grill (#5) onto the main unit (#8) making sure the three guiding slots are positioned correctly into the main unit's slots.
6. Fix the back grill (#5) by turning the back grill nut (#4) firmly in a clockwise direction
7. Pick up the fan blade (#3)
8. Place the fan blade (#3) onto the motor shaft (#7) so that both guiding slots rest on the rear of the fan blade (#3) on the mounting pin
9. Turn the fan nut (#2) in an anticlockwise direction, holding the fan blade (#3) whilst doing so.
10. Loosen the fixing screw from the back grill (#5) and open the side clips.
11. Pick up the front grill (#1)
12. Put the front grill (#1) into the mount on the underside of the back grill (#5) and align the screw holes on the upper side so that they are positioned above each other. Now secure the two grills with the two side clips and then tighten the fixing screw and nut with a screwdriver.
13. Unwind the cable. You have now successfully completed the assembling stage.

RobbWork.com
ENGLISH

OPERATING INSTRUCTIONS

1. Place the fan on a flat, dry surface.
2. Check that the operating switch (#9) is on position OFF (0). Put the plug into the socket
3. Turn the operating switch (#9) to the desired position:

0 OFF
1 Low speed
2 High speed
4. Loosen the tilting knob (#11) on the side of the motor and tilt the fan to the desired position. Then retighten the tilting knob (#11).
5. Pull the oscillation button (#10) out, in order to activate oscillation of the fan from left to right. Push the oscillation button (#10) in, in order to deactivate oscillation.
6. Please use the handle (#6) on the back grill (#5) for carrying the fan.
7. Turn the operating switch (#9) to the OFF position (0) and remove the plug from the socket when not in use.

CLEANING

1. Before commencing with cleaning of the fan, ensure that the operating switch (#9) is on position OFF (0). Remove the plug from the socket.
2. Use a clean, damp cloth to clean the exterior of the fan. Do not use petroleum spirit, thinners or any other chemicals. Use a vacuum cleaner with brush attachment to clean the grills.
3. Do not immerse the fan in water! Ensure that no water gets into the motor casing.
4. The fan can now be used as described under “**Operating Instructions**”.

CONDITIONS OF SALE

As a condition of sale, the customer assumes responsibility for the correct use and care of this fan in accordance with these operating instructions. The customer or user of the fan is responsible for deciding how long he/she uses the fan.

PLEASE NOTE: ANY DEFECTIVE PRODUCTS ARE TO BE RETURNED TO THE DEALER WHERE THEY WERE PURCHASED. PLEASE DO NOT ATTEMPT TO OPEN THE FAN OR TO REPAIR IT YOURSELF, SINCE THIS NULLIFIES THE GUARANTEE AND COULD CAUSE PHYSICAL INJURY OR DAMAGE TO THE FAN.